



MINIFLEX LR PROGRAMMABLE LEVEL CONTROLLER

INSTALLATION AND OPERATION MANUAL

FOR SOFTWARE MINIFLEX LR1.11 and later



Hycontrol Limited, Larchwood House, Orchard Street,
Redditch, Worcestershire, B98 7DP, UK.
Tel: +00 44 (0)1527 406800 Fax: +00 44 (0)1527 406810
Email: sales@hycontrol.com Web: www.hycontrol.com

MINIFLEX LR USER MANUAL - INDEX

		Page	Drawings
	Introduction	1	
SECTION 1	Installation		
	Transceiver Mounting	2	Fig. 1
	Transceiver Wiring	3 - 4	Fig. 2 & 3
	Transducer Mounting	5	Fig. 4
	Transducer Alternative Mounting	6	Fig. 5
	Transducer Mounting Faults	7	Fig. 6
	Transducer Stand Pipe	7	
	Transducer Cable Extensions	8	Fig. 7 & 8
SECTION 2	Quick start for Miniflex LR		
	Quick Start Guide	10	
	Principle of Programming	10	
	Keypad Definitions	10 - 11	
	To Enter Programme	11	
	To Enter the Password	11	
	To Change an Option	12	
	To Reset	13	
	Simulation Mode	13	
SECTION 3	Programming the instrument		
	Parameter List	14 - 34	
SECTION 4	Miniflex LR Default programs		
	1. Distance Measurement Mode	35	
	2. Level Measurement Mode	36	
	3. Contents, Volume Conversion	37	
	4. Pump Control	38	
	5. Open Channel Flow	39 - 40	
	6. Differential	41 - 42	
SECTION 5	Commissioning fault finding	43 - 47	
APPENDIX 1	LINEARISATION OF SPECIAL VESSELS OR FLUMES	48 - 52	
APPENDIX 2	SPECIFICATION	53	
APPENDIX 3	INSTALLATION INSTRUCTIONS FOR ATEX TRANSDUCER IN HAZARDOUS AREA	54 - 55	
APPENDIX 4	PARAMETER SETTINGS	56 - 62	
APPENDIX 5	PARSHALL FLUMES	63	
APPENDIX 6	WIRING DIAGRAM FOR SYNCHRONISATION OF INSTRUMENTS	64	
APPENDIX 7	PROGRAMMING CHARTS	65 - 74	

Major changes from previous issue

1. ATEX transducers added
2. Separate temperature probe deleted
3. Fuse F4 uprated to 500mA
4. Door security screws added

MINIFLEX LR PROGRAMMABLE LEVEL CONTROLLER**USER MANUAL****INTRODUCTION**

Miniflex LR is a programmable multi-purpose level measurement and flow control instrument. It consists of two elements, a wall mounted transceiver, which has a display and an integral keypad for programming, and a transducer, which must be mounted directly above the surface to be monitored.

Ultrasonic pulses are transmitted by the transducer to the surface of the material to be monitored and are reflected back to the transducer. The time period between transmission and reception of the sound pulses is directly proportional to the distance between the transducer and the material.

Since the speed of sound through air is affected by changes in temperature, a temperature-compensated transducer may be specified to improve accuracy .

Miniflex LR is capable of the following functions:-

- a) Distance Measurement (distance from a datum)
- b) Level Measurement (height above datum)
- c) Volume Measurement
- d) Pump Control
- e) Open Channel Flow Measurement (O.C.M.)
- f) Differential Level Measurement

WARNING

**DO NOT OPEN THE TRANSCEIVER
TERMINAL COVER WHEN THE POWER IS ON TO
THE SUPPLY OR RELAY TERMINALS.**

IMPORTANT INSTALLATION REQUIREMENTS

- 1: A SWITCH OR CIRCUIT BREAKER SHALL BE INCLUDED IN THE INSTALLATION**
- 2: IT SHALL BE IN CLOSE PROXIMITY TO THE EQUIPMENT AND WITHIN EASY REACH OF THE OPERATOR**
- 3: IT SHALL BE MARKED AS THE DISCONNECTING DEVICE FOR THE EQUIPMENT**
- 4: FOR ATEX INSTALLATIONS REFER TO APPENDIX 3**

INSTALLATION

Transceiver

Enclosure mounting

Ensure that the mounting surface is not subject to vibration and is not close to high voltage cables, contactors or drive controls. The unit should not be mounted in a confined space where temperatures may exceed the normal working temperature. If the unit is mounted outside, it must be protected from direct sunlight and severe weather conditions.

Remove the terminal cover, select knockouts in the base of the enclosure and fit cable glands to maintain the IP65 rating. Note that 3x M20 holes are already prepared.


Refer to the drawing below.

For mounting point 1, fix an M4 or M5 flat-head screw in the mounting surface, leaving a 4mm gap to the surface. Remove the terminal cover, hang the transceiver from the screw and secure it with 2x M4 or M5 flat-head screws at mounting points 2 & 3.

Do not use excessive force when tightening the screws and do not distort the enclosure.

Replace the terminal cover unless you now intend to proceed with wiring into the terminals.

After programming the unit refit the 2 screws to secure the enclosure door



ALL DIMENSIONS IN MM

Figure 1: Enclosure dimensional & mounting drawing

Electrical and Transducer Connections

The Miniflex LR has two-part screw terminals; the top part can be removed for ease of connection. It can be powered from either an AC or DC supply.

Power Supply

Remove the terminal cover to expose the terminals shown below.




Figure 2: Terminals as seen in Miniflex LR.

The wiring instructions are on the inside of the terminal cover as shown below.




Figure 3: Wiring diagram label inside Miniflex LR terminal cover

AC Supply

The instrument will accept either 95V, 110V or 230VAC $\pm 10\%$, 50Hz or 60Hz, 12VA. A time lag fuse T160mA is fitted.

Select the voltage required using the jumper link situated just above terminal TB6.

Pass mains cable through cable gland and - Connect:-
 Earth to terminal 23
 Neutral to terminal 24
 Live to terminal 25

DC Supply

The instrument will accept 21.6 - 30VDC, 7.5W. A time lag fuse T500mA is fitted.

- Connect :-
 Positive +ve to terminal 1
 Negative -ve to terminal 2

Relays

3 SPDT Relays - rated at 8A/250VAC 8A/30V DC resistive, are connected at terminals 14 to 22, for activating external alarms, contactors, pumps etc..

Transducer**Transducers RYVK15, RWVK15,****RYVK15-ATEX & RWVK15-ATEX - are connected:-**

Black	to terminal 6
Blue	to terminal 7
Shield	to terminal 9

Temperature compensated transducers RYTK15, RWTK15,**RYTK15-ATEX & RWTK15-ATEX - are connected:-**

Shield	to terminal 6
Blue	to terminal 7
Black	to terminal 8

Analogue Output**Analogue - is connected:-**

Shield	to terminal 11
Positive +ve	to terminal 12
Negative -ve	to terminal 13

RS485 Output**RS485 - is connected:-**

Shield	to terminal 3
Negative -ve	to terminal 4
Positive +ve	to terminal 5

Note: - See Page 8 for transducer extension cables.

Note:- When using temperature compensated transducer type RYTK15-ATEX or RWTK15-ATEX, software must be Miniflex LR1.11 or later; see Pr.12.11 on page 34. This software version defaults to operate these types of transducer. If your unit has earlier software, contact Hycontrol for advice.

If you are using an older transducer, type RYT15, RYTK15, RWT15 or RWTK15 i.e. without the suffix “ATEX”, you must select “12.14.2 Trans R*TK15” at Pr.12.14 (see page 34)

This note does not apply to transducers without temperature compensation i.e. RYV15, RYVK15, RYVK15-ATEX, RWV15, RWVK15, RWVK15-ATEX

Transducer Mounting

The transducer can be supplied as 'standard' or mounted in a flange. For improved chemical compatibility the transducer is available fully enclosed in PVDF in a standard mounting or with a flange. Figure 4 shows the dimensions:




Figure 4: Transducer dimensions

An isolation kit is provided with each transducer to minimise any ringing transmitted through the mounting structure.

The transducer must be mounted perpendicular to the monitored surface and, ideally, at least 0.5 metres above it.

The transducer has a 12° inclusive conical beam angle at -3dB and must be mounted with a clear unobstructed sight of the liquid to be measured over the complete measurement range.

The transducer is provided with integral cable which can be extended up to 300 metres using a suitable junction box and RG62AU cable. The temperature compensated transducer requires an additional single core screen extension, or twin-axial cable.

Refer to Page 8 for full details.

Transducer cables should be separated from power cables by at least 150mm and preferably installed in their own earthed steel conduit.




Figure 5: Alternative mounting arrangements for transducers

Do not mount transducers incorporating temperature compensation in direct sunlight.

Do not over-tighten the bolts on flange construction transducers.

Flange transducers are not pressure rated and are suitable only for atmospheric pressure.

ATEX approved transducers must be mounted and wired in accordance with the appropriate National Standards concerning installation in hazardous environments for Ex mb equipment.

For differential applications mount both transducers at the same height above the zero datum point.
For open channel flow applications the transducer must be mounted upstream of the flume or weir as detailed in BS3680 (usually 3 or 4 times maximum head).




Figure 6: Transducer installation faults

Standpipe Installations

In many applications access to a vessel must be made via a standpipe. However, it is necessary to observe some basic rules when fitting transducers into standpipes.

BLANKING: Parameter 4.0 should always be set at least 150mm longer than the length of the standpipe.

STANDPIPE DIMENSIONS: Should be in accordance with the following table

<u>Flange size and minimum bore of standpipe</u>		<u>Maximum length of standpipe</u>
3"	(80mm)	300mm
4"	(100mm)	300mm

e.g. Using a 4" flanged transducer would require the standpipe length to be no more than 300mm and Pr.4.0 set at 450mm minimum.

The inside of the pipe and joint with vessel top must be clean and free of any obstructions, seams or welds.

Transducer Cable Extensions

Transducer cables may be extended using junction boxes as shown in Figure 7:

Note! For ATEX installations refer to BS EN 60079-14 (current issue)




Figure 7: Transducer cable extension diagram




Figure 8: Transducer wiring for differential mode

THIS PAGE IS INTENTIONALLY LEFT BLANK

QUICK START FOR MINIFLEX LR

The Miniflex LR system requires programming by the operator to obtain the required measurements and control. To create a basic working system, only the application type and parameters 2.0 to 5.0 need be programmed. To become familiar with the use of the system, it is suggested that the following QUICK START guide is used before the instrument is installed.

Refer to the notes on page 4 before starting.

Quick Start Guide

1. Connect power and transducer cables as defined on the instrument.

	<u>dc Power Supply</u>		<u>Temperature compensated Transducer</u>			<u>ac Power Supply</u>		
Terminal Nos:	[1]	[2]	[6]	[7]	[8]	[23]	[24]	[25]
	+ve	-ve	Shield	Blue	Black	E	N	L

2. Close the front cover and secure in position before switching on the power. The instrument is supplied factory set to work in distance measurement up to 10 metres from the transducer.
3. Hold the transducer approximately 1.5 metres from a flat surface and switch on.

After a short period, the display will show the distance (e.g. 1.50) between the transducer and the surface.

If the transducer is now moved slowly towards the surface, the reading should decrease. This shows that the unit is correctly wired and is operating as expected in response to the reduction in distance.

If the reading increases as the transducer is moved towards the surface, it indicates that the unit has been previously programmed to read level not distance.

Principle of Programming

The Miniflex LR has two modes:-

- a) **RUN (Normal operating)**
In the 'RUN' mode, the instrument is monitoring the target, displaying values and setting outputs as programmed by the operator.
- b) **Program Mode (Programming)**
In the 'Program Mode' the operator uses the keypad in conjunction with the display to adjust the settings and to test that the unit is programmed correctly.

Keypad Definitions

The keypad consists of 5 keys which are used to programme the operation of the transceiver. These keys also have secondary functions enabling the operator to view the results being obtained by the instrument during its normal 'RUN' cycle.

Primary Key Functions

M	= Mode Key - to go from "RUN" to "Program Mode" - or to go from "Program Mode" to "RUN" Mode	
ENT	= ENTER - to enter a value or option change or start a simulation if parameter 12.5.2 is entered.	
↑	= In program mode to increase the selected digits value.	
↶	= To move back to the main sections of parameters.	
↷	= Scroll through options or move cursor to the right if there is a value.	

Alternative Key Functions

The 4 peripheral keys have secondary functions which can be viewed without interrupting the instrument's operation. In the normal "RUN" mode:-

- Press **↑** = Display will show head and flow values when in OCM mode.
- Press **↷** = Display will show the echo distance in metres and "GAIN" with a value from 0.2 to 100, which represents strength of echo. Low numbers mean strong echo.
- Press **↶** = Display will show the operating temperature if using a temperature compensated transducer or 20°C with standard transducer, and the analogue output value in mA.
- Press **ENT** = Display will show the number of Alarms and Starts for relay 1, if the button is pressed again whilst displaying the value for relay 1 it will change to relay 2 and if pressed again relay 3.

NOTE:- The Miniflex LR comes with pre-programmed applications, which can be simply modified to meet your applications requirements. See SECTION 4 for more details.

1) To Enter Programme

- Press **M** - Display will show "Program Mode"
- Press **↑** immediately - Display will show either Distance Measurement, Level Measurement, Volume Measurement, Pump Control, Open Channel Flow Monitoring or Differential Measurement.

If you wish to change the selected application press **↷** to move through the applications, you will be asked to enter the password.

2) To Enter the Password

The first time that you try to change the application, a value or a parameter option, you will be required to enter the password. The default for this is 1000. You use the **↑** and the **↷** to change the digits then **ENT** when you have finished, if you enter the wrong code the display value will be cleared and you will need to try again.

3) To Accept the Current Selection press ENT

Continue to press **ENT** - To accept the value or option and move to the next applicable parameter.

4) To Change the Value of a Number

Press **↑** - To increase value of flashing digit between 0 and 9. It will then roll over to its minimum and start again.

Press **↻** - To move the cursor right and select the next digit to be changed, then Press **↑** to change its value as above.

Press **ENT** - To enter the new value. The display will then show the next parameter in the list.

5) To Change a Y or N Option

Certain parameters have been put into sections to avoid stepping through numerous parameters that you may not need to change initially. Each of the sections will have a Yes or No option.

8.0 Edit relays
No

To change the relay settings use the **↑** to change a 'No' to a 'Yes' or to skip that section just press **ENT**.

8.0 Edit relays
Yes

When you have made your selection press **ENT** to move to the next parameter.

6) To Change an Option

A display which shows a label enclosed in brackets means that this is the currently selected value for this parameter, but it can be changed.

e.g.

8.1 Rly1 Options
(Norm-Energised)

Press **ENT**
To change value press **↑**

8.1.1 Relay 1
Norm - Energised

Press **↻** to change the option

8.1.2 Relay 1
Norm-DeEnergised

Press **↻** to change the option again

8.1.3 Relay 1
Temp Alarm

When you come to the option you want press **ENT** to accept the new selection and move on the next parameter in the list.

(Shortcut for more familiar users)

Alternatively if you don't need to make a change to this parameter and its associated settings you can move to the next parameter in the top level by using the  key.



When you come to a parameter you want to adjust press **ENT** and follow step **4)**, **5)** or **6)** depending on whether there is a value to enter, a yes or no option or select an option.

7) To complete Programming and Return to RUN Mode

Press **M** - The display will show "Storing Values" and "Data stored to memory", if a value has been changed. Then "Searching for target" and then the measured value in the selected units.

8) To Reset all Parameters to Factory Default

Press **M** if not already in program mode - Displays "Program mode".

Press  To display a parameter (it can be any one)

To reset the instrument you need to display the first parameter of any application i.e. Distance Measurement, Level Measurement, Volume Measurement, Pump Control, Open Channel Flow Monitoring or Differential Measurement. If it is not displayed, use the  key to move back through the program to the first parameter.

Then press both  and  simultaneously and when prompted Enter the password. The instrument will reset the parameters, custom tables and totaliser, and reverts back to displaying Distance Measurement.

Simulation mode

To simulate a program go to parameter

12.5.2 Simulate Yes

 then press **ENT**.

Keys

- M** = Exits simulation mode
- ENT** = Direction to decrease displayed value
-  = Direction to increases displayed value
-  = Reduce speed by 2 from a maximum of 64x to 1x. The initial speed of 1x is set by the rate of change defined in parameter 6.0.
-  = Increase speed by 2. From 1x to a maximum of 64x.

PARAMETER INDEX
MINIFLEX LR

Application

Pr. 1.0 Basic Application

Basic Set-up

Pr. 2.0 Empty Distance
Pr. 3.0 Operational Span
Pr. 4.0 Blanking
Pr. 5.0 Rate Of Change

Volume Measurement

Pr. 6.1 Vessel shape
Pr. 6.2 Display Units
Pr. 6.3 Maximum Display x 100
Pr. 6.4 Display Format

Open Channel Flow Monitoring (O.C.M.)

Pr. 7.1 Flow device
Pr. 7.2 Maximum Flow Value Type
Pr. 7.3 Maximum Flow
Pr. 7.4 Totaliser Units
Pr. 7.5 External Totaliser Drive
Pr. 7.6 Totaliser Reset

Relays

Pr. 8.1 Relay1 Options
Pr. 8.2 Relay2 Options
Pr. 8.3 Relay3 Options

Pump Control

Pr. 9.1 Pump Sequence
Pr. 9.2 Duty Standby
Pr. 9.3 Exerciser
Pr. 9.4 Tolerance
Pr. 9.5 Maintenance
Pr. 9.6 Pump Run-on Interval
Pr. 9.7 Pump Run-on Time

Failsafe

Pr. 10.1 Relay 1 Failsafe
Pr. 10.2 Relay 2 Failsafe
Pr. 10.3 Relay 3 Failsafe
Pr. 10.4 Fail Time
Pr. 10.5 mA Fail

Analogue

Pr. 11.1 Analogue Output
Pr. 11.2 Analogue Value
Pr. 11.3 Test mA
Pr. 11.4 Analogue Scale

Miscellaneous

Pr. 12.1 Offset
Pr. 12.2 Passcode
Pr. 12.3 Number Of Decimals
Pr. 12.4 Relay totaliser
Pr. 12.5 Simulation
Pr. 12.6 Station ID
Pr. 12.7 Synchronisation
Pr. 12.8 Check Search
Pr. 12.9 Maximum gain
Pr. 12.10 Serial No.
Pr. 12.11 Version No.
Pr. 12.12 Echo velocity
Pr. 12.13 Gain control
Pr. 12.14 Transducer

PROGRAMMING THE INSTRUMENT

NOTE:- (D =) factory default entry for that parameter.

Step 1: - Select application (Pr.1.0)**Application (D = Distance Measurement)**

This will automatically load the applicable default program which can then be modified to suit your application.

At initial start up display will show one of below listed options: -

Distance Measurement	(Page 35)
Level Measurement	(Page 36)
Volume Measurement	(Page 37)
Pump Control	(Page 38)
Open Channel Flow Monitoring	(Pages 39 – 40)
Differential Measurement	(Pages 41 – 42)

For more details see Pr.1.0 Application Selection Guide (Page 16)

Step 2: - Enter Basic Set-up parameters

Complete Basic Set-up section - Page 17

Step 3: - Dependent on application, go to appropriate section in manual.

For Distance Measurement go to Page 35.

For Level Measurement go to Page 36.

For Volume Measurement go to Page 37.

For Pump Control go to Page 38.

For Open Channel Flow Monitoring go to Pages 39 - 40.

For Differential Measurement go to Pages 41 - 42.

Step 4: - Set any relay conditions

Relay section go to Pages 24 - 26

Step 5: - Set any failsafe conditions

Failsafe section go to Page 30

Step 6: - Set any analogue conditions

Analogue section go to Pages 31 - 32

Step 7: - Set any miscellaneous conditions

Miscellaneous section go to Pages 33 - 34

Step 8: - Exit program mode and return to run mode

Go to Section 7 Page 13

Pr.1.0 APPLICATION SELECTION GUIDE

Miniflex LR can be programmed for Distance measurement, Level measurement, Volume measurement, Pump control, OCM and Differential measurement. Each application selected will allow access to only parameters associated with that application.

Distance Measurement

Displays a distance measurement; relay set and reset points can be programmed and a relay can be programmed for Loss Of Echo indication. A 4-20mA output proportional to the displayed distance is provided.

Level Measurement

Displays a level; relay set and reset points can be programmed and a relay can be programmed for Loss Of Echo indication. A 4-20mA output proportional to level is provided.

Volume Measurement

Displays contents, ullage or both contents and ullage. Choose from a variety of vessel shapes including vertical and horizontal cylinders or a 24-point custom table. Display in Litres, Gallons, Tons, Tonnes, Kg, m³ or %. Provide a 4-20mA output proportional to contents or ullage.

Pump Control

For pump control applications; can include pump sequencing, duty standby, pump maintenance and pump run on.

Open Channel Flow Monitoring (O.C.M.)

For flow measurement, using BS3680 flumes and weirs, Parshall flumes, or custom table for non-standard devices. Displays flow rate in litres/sec or gallons/sec and totalises in a variety of units. Provides a pulse output to drive an external totaliser and a 4-20mA output proportional to level or flow.

Differential Measurement

Uses two transducers switched automatically. The display indicates the difference between two levels and gives a 4-20mA output proportional to the reading. Relay set and reset points can be programmed and a relay can be programmed for Loss Of Echo indication.

Basic Set-up**Pr.2.0 Empty Dist** Empty Distance in Metres

	Distance	Level	Volume	Pump	OCM	Differential
Default	10.00	6.000	6.000	6.000	1.200	2.000

The approximate distance from the face of transducer to the furthest point away, usually the bottom of the container or channel. Enter the distance in metres.

Resolution is a function of this parameter.

Pr.3.0 Span Operational Span in Metres

	Distance	Level	Volume	Pump	OCM	Differential
Default	10.00	5.500	5.500	5.500	0.280	0.500

The distance between the furthest and nearest points over which measurement is required. Enter the distance in metres.

For OCM, span = maximum head.

For differential applications, the value required is the maximum difference in the levels to be measured.

Pr.4.0 Blanking (D = 0.500 Metres)

Blocking or Blanking Zone.

Minimum distance from transducer face to target, within which no return echoes will be processed. It is important to ensure that the target material does not enter this zone.

Enter in metres.

DO NOT REDUCE THE FACTORY SET VALUE WITHOUT REFERENCE TO HYCONTROL.

Pr.5.0 RateOfChange Rate Of Change in Metres/Min


	Distance	Level	Volume	Pump	OCM	Differential
Default	10.00	1.000	1.000	1.000	1.000	1.000

This value should be as small as possible but greater than the maximum rate of change of level. **Do not** change this value unless you know that the rate of change is greater than 1.0m/min or that the system continually 'tracks' a level lower than the actual level.

If it is necessary to change the value, enter the new value in m/min; the suggested range is 0.1 to 10.

Volume Measurement

The following main parameters set up a volume measurement application.



Pr.6.1 Vessel shape (D = Linear)


Options displayed

- 6.1.1 Linear Vessel
- 6.1.2 Vertical Pyramid Bottom
- 6.1.3 Vertical Conical Bottom
- 6.1.4 Vertical Spherical Bottom
- 6.1.5 Vertical Dished Bottom
- 6.1.6 Horizontal Cyliind Flat Ends
- 6.1.7 Horizontal Cyliind Dish Ends
- 6.1.8 Custom table – 24point


Description

- Linear vessel
- Vertical cylindrical tank with pyramid bottom
- Vertical cylindrical tank with conical bottom
- Vertical cylindrical tank with half spherical bottom
- Vertical with dished bottom
- Horizontal cylinder with flat ends
- Horizontal cylinder with dished ends
- 24 point linearisation table – See appendix 1


Additional parameters may be required dependent on vessel shape selection.




No additional parameters




Pr 6.1.2.1 Pyramd h (D = 0.00)
Enter pyramid h in metres.



Pr 6.1.3.1 Cone h (D = 0.00)
Enter cone h in metres.



Pr 6.1.4.1 Sphere h (D = 0.00)
Enter sphere h in metres.



6.1.5 VERTICAL DISHED BOTTOM.

Pr 6.1.5.1 Dish h (D = 0.00)


Enter dish h in metres.

Pr 6.1.5.2 Radius R (D = 0.00)

Enter radius R in metres.



6.1.6 HORIZONTAL CYLINDER FLAT ENDS.

No additional parameters

6.1.7 HORIZONTAL CYLINDER DISHED ENDS.

Pr 6.1.7.1 Dish L (D = 0.00)

Enter dish L in metres.

Pr 6.1.7.2 Cylndr L (D = 0.00)

Enter cylinder L in metres.

Pr. 6.2 DisplayUnits Display Units (D = %)Options displayed**6.2.1 Units Litres****6.2.2 Units Gallons****6.2.3 Units Tons****6.2.4 Units Tonnes****6.2.5 Units Kg****6.2.6 Units m3****6.2.7 Units %**Description

Units label displayed in Litres

Units label displayed in Gallons

Units label displayed in Tons

Units label displayed in Tonnes

Units label displayed in Kg

Units label displayed in m3

Units label displayed in %

Pr. 6.3 MaxDsp x 100 Maximum display x 100 (D = 1.0)Enter - full scale display \div 100e.g. if 100% = 2000 litres and display required in litres then set Pr. 6.3 to $2000 \div 100 = 20$.

This parameter should not be adjusted in conjunction with **6.2.7 Units %** as it will invalidate the % reading.

Pr. 6.4 Disp. Format Display Format (D = Contents)Options displayed**6.4.1 Display Contents****6.4.2 Display Ullage****6.4.3 Display Ullage &Contents**Description


Display contents only

Display ullage only

Display both ullage and contents

Open Channel Flow Monitoring (O.C.M.)

The following main parameters set up an Open Channel Flow Monitoring application.




Pr.7.1 Flow device (D = Rect. Flume 3/2)

The instrument provides options for three standard ratio-metric flow devices, three BS3680 flow devices, a variety of Parshall flumes or a custom 24-point table.

Select the flow device from the following list.

<u>Options displayed</u>	<u>Description</u>	<u>Action</u>
7.1.1 Std. Ratio Rect. Flume 3/2	Standard Ratio Rectangular flume 3/2	
7.1.2 Std. Ratio Rect. Weir 3/2	Standard Ratio Rectangular weir 3/2	
7.1.3 Std. Ratio V-Notch Weir 5/2	Standard Ratio V-notch weir 5/2	
7.1.4 BS3680 Rect. flume	BS3680 Rectangular flume	* Follow BS3680 set-up at step A
7.1.5 BS3680 Rect. weir	BS3680 Rectangular weir	* Follow BS3680 set-up at step B
7.1.6 BS3680 V-notch weir	BS3680 V-notch weir	* Follow BS3680 set-up at step C
7.1.7 Parshall Flumes	Parshall Flumes	* Follow PARSHALL set-up step D
7.1.8 Custom table	24-point linearization table.	Refer to Appendix 1

BS3680 set-ups




Step D: -

Select from one of the following options for a Parshall flume
(See also Appendix 5)

<u>Options displayed</u>	<u>Description - Parshall flume type</u>
7.1.7.1 Parshall 1,2,3,24 inches	1,2,3 or 24 inches
7.1.7.2 Parshall 6 inches	6 inches
7.1.7.3 Parshall 9 inches	9 inches
7.1.7.4 Parshall 12 inches	12 inches
7.1.7.5 Parshall 18 inches	18 inches
7.1.7.6 Parshall 36 inches	36 inches
7.1.7.7 Parshall 48 inches	48 inches
7.1.7.8 Parshall 72 inches	72 inches
7.1.7.9 Parshall 96 inches	96 inches
7.1.7.10 Parshall 10 – 50 feet	10 to 50 feet

Pr. 7.2 Max Flow Val * Only applies if 7.1 set to BS3680 Maximum Flow Value (D = Auto calculation)

There are two types of calculation either *Auto calculate*, if you want the instrument to calculate the flow automatically or *Input by User* if you want to enter the flow value manually.



<u>Options displayed</u>	<u>Description</u>	<u>Action following selection</u>
7.2.1 Automatic Calculation	This option calculates maximum flow based on the entered flume or weir values and the maximum head in metres @ Pr.3.0 Span . The calculated flow is stored in litres/sec @ Pr.7.3.1.	Calculates a new flow value based on entered parameters and rewrites this flow in litres/sec then displays this value in Pr.7.3
7.2.2 User sets maximum flow	Selecting this option requires you to enter manually the maximum flow corresponding to the maximum head (Pr.3.0) using units selected @ 7.4/7.5. Enter maximum flow @ PR. 7.3.1.	Displays Pr.7.3.1. does not modify the existing entered value.

Pr. 7.3 Maximum Flow (D = 50.00)

Enter the maximum flow rate in selected units corresponding to maximum head, set at Pr. 3.0

<u>Text displayed</u>	<u>Description</u>
7.3.1 Max. Flow 50.00	Maximum Flow

Note

1. If you are using a BS3680 flume or weir in auto calculate mode the maximum flow will be calculated in l/sec and stored by the instrument, overwriting any previous value.

Pr.7.4 Flow Units (D = in Litres)

<u>Option displayed</u>	<u>Description</u>
7.4.1 Flow Units in Litres	Flow Units in Litres
7.4.2 Flow Units in m3	Flow Units in m3
7.4.3 Flow Units in Gallons	Flow Units in Gallons

Select from one of the above options: -

Pr.7.5 Flow Timebase (D = in units per second)

<u>Option displayed</u>	<u>Description</u>
7.5.1 in units per second	Flow timebase in units per second
7.5.2 in units per minute	Flow timebase in units per minute
7.5.3 in units per hour	Flow timebase in units per hour
7.5.4 in units per day	Flow timebase in units per day

Select from one of the above options: -

Pr.7.6 Total. Units Totaliser Units (D = m3)

<u>Option displayed</u>	<u>Description</u>
<i>Metric measurement</i>	
7.6.1 Totalise In Litres	Totalise flow in Litres
7.6.2 Totalise In m3	Totalise flow in m3
7.6.3 Totalise In 1000 m3	Totalise flow in 1000 m3
<i>Imperial measurement</i>	
7.6.4 Totalise In Gallons	Totalise flow in Gallons
7.6.5 Totalise In 1000Gals (kG)	Totalise flow in 1000 Gallons
7.6.6 Totalise In Million Gallons	Totalise flow in Million Gallons

Select from one of the above options: -

Note: You cannot mix metric and imperial units at PR. 7.4 / Pr. 7.6

Pr.7.7 Ext. Tot. Dri. External Totaliser Drive (D = 0.000)

If **8.3 Rly 3 option** (Page 26) is set to "**Totaliser Out.**" (**8.3.6**), then enter the amount, which each relay trip is to represent.

<u>Text displayed</u>	<u>Description</u>
7.7.1 Tot. Dri.	On every multiple of this parameter output a pulse to drive an external totaliser.

e.g.

7.7.1 Tot. Dri. = 0.000

External Totaliser Drive is disabled.

7.7.1 Tot. Dri. = 1.000

If "Totalise in Litres" selected at 7.6 then relay output is tripped every litre

If "Totalise in m3" selected at 7.6 then relay output is tripped every cubic metre (m3)

If "Totalise in 1000m3" selected at 7.6 then relay output is tripped every 1000 cubic metres (1000m3)

7.7.1 Tot. Dri. = 1000

If "Totalise in Litres" entered at 7.6 then relay output is tripped every cubic metre (m3)

After making entries in Pr.7.7.1, go to Pr.7.8 to clear and initiate totaliser.

Pr.7.8 Total. Reset Relay Hours/Starts Totaliser Reset (D = No)

<u>Option displayed</u>	<u>Description</u>
7.8.1 Totaliser Reset No	No effect on totaliser
7.8.2 Totaliser Reset Yes	Resets the totaliser to 0

To clear the totalisers select the following:

7.8.2 Totaliser Reset Yes

The following messages "Totaliser reset" then "Totaliser stored" appear on the screen.

Note

1. Pr. 7.8 will never display (Yes) even after the totaliser is reset.

Relays

The 3 relays can be assigned to various functions depending on the application, as shown below:

Hysteresis is fully adjustable, so for most functions it is necessary to enter both "set" and "reset" values.

The relay state under normal operating conditions is defined as:-

Normally energised. De-energise when "set" value is reached.

Normally de-energised. Energise when "set" value is reached.

"Failsafe" functions are detailed in Pr.10.1 – 10.5.


The relays can be programmed to give both high and low alarm or control levels.

e.g. High alarm Set: 2.0m Low Alarm Reset: 0.5m
 Reset 1.8m Set 0.2m

The system will automatically configure itself as high or low alarm depending on which of the set and reset entries has the higher value.

Note that in distance measurement mode set by Pr 1.0, the highest value is furthest from the transducer.

The relays are controlled using parameter section 8.0 as follows: -



*1 See Pr.8.1 Relay 1 Options default table below

*2 See Pr.8.2 Relay 2 Options default table on Page 25

*3 See Pr.8.3 Relay 3 Options default table on Page 25

Pr.8.1 Rly1 Options Relay 1 Options

The default setting for Rly1 Options is dependent on the application as shown in the following table: -

	Distance	Level	Volume	Pump	OCM	Differential
Default	Off	Norm-Energised	Norm-Energised	Norm-DeEnerg	Flow Alarm	Diff Control

Relay 1 options in *Distance, Level, Volume, Pump* and *OCM* mode: -

<u>Options displayed</u>	<u>Description</u>
8.1.1 Relay 1 Norm-Energised	Relay 1 Normally Energised
8.1.2 Relay 1 Norm-DeEnergised	Relay 1 Normally De-Energised
8.1.3 Relay 1 Temp Alarm *⁵	Relay 1 Temperature alarm (Normally Energised)
8.1.4 Relay 1 L.O.E. Alarm	Relay 1 L.O.E. Alarm (Normally Energised)
8.1.5 Relay 1 Off	Relay 1 Off
8.1.6 Relay 1 Flow Alarm *⁴	Relay 1 Flow Alarm (Normally Energised)

Options 8.1.1, 8.1.2, 8.1.3 and 8.1.6 require relay set and reset points to be entered in the units indicated on the display, except volume where they are set in percent.

Relay 1 options in *Differential* mode: -

<u>Options displayed</u>	<u>Description</u>
8.1.1 Relay 1 Differ. Alarm	Relay 1 Differential Alarm (Normally Energised)
8.1.2 Relay 1 Differ. Control	Relay 1 Differential Control (Normally De-Energised)
8.1.3 Relay 1 Temp Alarm *⁵	Relay 1 Temperature alarm (Normally Energised)
8.1.4 Relay 1 L.O.E. Alarm	Relay 1 L.O.E. Alarm (Normally Energised)
8.1.5 Relay 1 Off	Relay 1 Off
8.1.6 Relay 1 Downstream Alarm	Relay 1 Downstream Alarm (Normally Energised)
8.1.7 Relay 1 Upstream Alarm	Relay 1 Upstream Alarm (Normally Energised)
8.1.8 Relay 1 Alarm on Up/Down	Relay 1 Alarm on both Upstream and Downstream (Normally Energised)

Options 8.1.1, 8.1.2, 8.1.3, 8.1.6, 8.1.7 & 8.1.8 require relay set and reset points to be entered in the units indicated on the display.

Pr.8.2 Rly2 Options Relay 2 Options

The default setting for Rly2 Options is dependent on the application as shown in the following table: -

	Distance	Level	Volume	Pump	OCM	Differential
Default	Off	Norm-Energised	Norm-Energised	Norm-DeEnerg	L.O.E.	Upstream Alarm

Relay 2 options in *Distance, Level, Volume, Pump* and *OCM* mode: -

<u>Options displayed</u>	<u>Description</u>
8.2.1 Relay 2 Norm-Energised	Relay 2 Normally Energised
8.2.2 Relay 2 Norm-DeEnergised	Relay 2 Normally De-Energised
8.2.3 Relay 2 Temp Alarm *⁵	Relay 2 Temperature alarm (Normally Energised)
8.2.4 Relay 2 L.O.E. Alarm	Relay 2 L.O.E. Alarm (Normally Energised)
8.2.5 Relay 2 Off	Relay 2 Off
8.2.6 Relay 2 Flow Alarm *⁴	Relay 2 Flow Alarm (Normally Energised)

Options 8.2.1, 8.2.2, 8.2.3 and 8.2.6 require relay set and reset points to be entered in the units indicated on the display, except volume where they are set in percent.

*⁴ Option only available in OCM mode

*⁵ Requires t/comp transducer

Relay 2 options in *Differential* mode: -

Options displayed

8.2.1 Relay 2 Differ. Alarm

8.2.2 Relay 2 Differ. Control

8.2.3 Relay 2 Temp Alarm *5

8.2.4 Relay 2 L.O.E. Alarm

8.2.5 Relay 2 Off

8.2.6 Relay 2 Downstream Alarm

8.2.7 Relay 2 Upstream Alarm

8.2.8 Relay 2 Alarm on Up/Down

Description

Relay 2 Differential Alarm (Normally Energised)

Relay 2 Differential Control (Normally De-Energised)

Relay 2 Temperature alarm (Normally Energised)

Relay 2 L.O.E. Alarm (Normally Energised)

Relay 2 Off

Relay 2 Downstream Alarm (Normally Energised)

Relay 2 Upstream Alarm (Normally Energised)

Relay 2 Alarm on both Upstream and Downstream (Normally Energised)

Options 8.2.1, 8.2.2, 8.2.3, 8.2.6, 8.2.7 & 8.2.8 require relay set and reset points to be entered in the units indicated on the display.

Pr.8.3 Rly3 Options Relay 3 Options

The default setting for Rly3 Options is dependent on the application as shown in the following table: -

	Distance	Level	Volume	Pump	OCM	Differential
Default	L.O.E.	L.O.E.	L.O.E.	L.O.E.	Totaliser Output	N/A

Relay 3 options: -

Options displayed

8.3.1 Relay 3 Norm-Energised

8.3.2 Relay 3 Norm-DeEnergised

8.3.3 Relay 3 Temp Alarm *5

8.3.4 Relay 3 L.O.E. Alarm

8.3.5 Relay 3 Off

8.3.6 Relay 3 Totaliser Output *4

Description

Relay 3 Normally Energised

Relay 3 Normally De-Energised

Relay 3 Temperature alarm (Normally Energised)

Relay 3 Loss Of Echo Alarm (Normally Energised)

Relay 3 Off

Relay 3 Output pulse to external totaliser (Normally De-Energised)


*4 Option only available in OCM mode

*5 Requires t/comp transducer

Options 8.3.1, 8.3.2 and 8.3.3 require relay set and reset points to be entered in the units indicated on the display, except volume where they are set in percent.

Pump Control

The following main parameters set up a Pump Control application.



Pr.9.1 PumpSequence Pump Sequence (D = Alternate pumps 1&2)

In order to even out the wear of pumps it is possible to alternate the sequence in which pumps are used.

Select the sequence from the following list.

Options displayed

- 9.1.1 Off
- 9.1.2 Alternate pumps 1 & 2
- 9.1.3 Alternate pumps 1,2 & 3

Description

- Sequence by set points (i.e. no alternation).
- Alternate Relay 1 and Relay 2 (1-2 / 2-1 etc.)
- Alternate Relay 1, Relay 2 and Relay 3 (1,2,3 / 2,3,1 / 3,1,2 etc.)

NOTE: When using Pr.9.1 with Pr.9.2 set to 9.2.2 or 9.2.3: -

1. All switch-off points should be set at the same level
2. Do not include alarm function relays in duty/standby routines.

Pr. 9.2 Duty Standby (D = Duty Assist)

Duty assist is where pumps are switched on by set point, and kept on to assist earlier pumps. Duty standby is where only one of the pumps specified for duty can be on at a time, i.e. when the set point for the second pump is reached and it switches on, the first pump will switch off.

Select the duty sequence from the following list.

Options displayed

- 9.2.1 Duty Assist
- 9.2.2 Duty Standby 1 & 2
- 9.2.3 Duty Standby 1,2 & 3

Description

- Duty/assist operation
- Duty/standby on pumps 1 and 2
- Duty/standby on pumps 1, 2 and 3

The turn-off points for the pumps can all be the same, or they can be different depending on the chosen "Set" and "Reset" values for each relay – unless using alternating sequence at Pr.9.1.

Pr.9.3 Exerciser (D = 0001)

To use this facility, first select alternating duty options 9.1.2 or 9.1.3 in Pr.9.1, depending on the number of pumps installed.

Enter the number of starts assigned to Pump 1 before the sequence switches to allow the other pumps to be exercised in turn.

Pr.9.4 Tolerance (D = No Tolerance)

In applications where a greasy topped liquid is being pumped, problems may occur due to build-up of grease at the levels where pumping starts. It is usually necessary for this to be cleared manually. To avoid this, varying the "turn on" point for the pumps by $\pm 10\%$ of the set point value causes the build-up to occur over a larger area, significantly reducing the maintenance problem.

Select the tolerance setting from the following list.

<u>Options displayed</u>	<u>Description</u>
9.4.1 No Tolerance	No tolerance applied to pumps
9.4.2 Tolerance On	Tolerance applied to all pumps

NOTE: The programmed pump "reset" points must be outside the 10% tolerance zone and outside the blanking distance Pr.4.0.

Pr.9.5 Maintenance (D = All pumps in)

The removal of one pump for maintenance can necessitate a great deal of readjustment to ensure correct control. Pr.9.5 simplifies this by allowing one pump to be removed without affecting the control levels. Pumps are re-assigned downwards so that the highest level is not used, therefore, normal control levels are maintained for lower level settings.

Select the pump maintenance sequence from the following list.

<u>Options displayed</u>	<u>Description</u>
9.5.1 All pumps in	All pumps in
9.5.2 Drop out pump 1	Drop out pump 1
9.5.3 Drop out pump 2	Drop out pump 2
9.5.4 Drop out pump 3	Drop out pump 3

- NOTE:**
- a. The system assumes that the lower numbered pumps turn on first.
 - b. **CAUTION - A PUMP NOT INCLUDED IN AN ALTERNATING SEQUENCE BUT PROGRAMMED INTO THE FIXED PART OF THE SEQUENCE WILL BE SUBSTITUTED INTO THE ALTERNATING SEQUENCE TO REPLACE A PUMP DROPPED OUT.**
 - c. This feature should not be used if the relays are being used for a mixture of pump control and alarm functions.

Pr.9.6 RunOnInterval Pump Run-on Interval (D = 0.00)

When submersible pumps are used, it may be necessary to pump down occasionally to clear the sludge from the bottom of the well. This feature is controlled by Pr.9.6 and Pr.9.7. Once in every interval defined by Pr.9.6, the pump will run-on for the time period defined by Pr.9.7.

Enter the time interval in hours between each run-on cycle.

Pr.9.7 Pump Run-on Time (D = 0)

Enter the pump running time in seconds. Maximum 120 seconds.

Only one run-on cycle occurs per interval as set by Pr.9.6.

- NOTE:**
- a. Caution is required when choosing a value for pump run-on time, as extended pump run-on can lead to cavitation, causing air locks or pump damage.
 - b. As overflow can occur, **do not** use pump run-on for pump up operation, set Pr.9.6 and Pr.9.7 to zero.
 - c. Care should be taken if pump sequence and pump run-on are defined together, as pump run-on will be assigned to the last pump to turn off, which could be any of those in the sequence.

Note!

If turn-off points are all the same, run-on will be by the last pump to turn on.

If 2 or 3 pumps have the same turn-on points, there will be a delay of 3-5 seconds between each pump turn-on; the alternating sequence be maintained.

Failsafe

On loss of power all relays will de-energise.

For other fault conditions e.g. damaged transducer, the failsafe relay state (after time delay selected at Pr.10.4), is selectable:-

Pr.10.1 Relay 1 Relay 1 Failsafe

	Distance	Level	Volume	Pump	OCM	Differential
Default	Hold State	Hold State	Hold State	De-Energise	Hold State	Hold State

Options displayed

- 10.1.1 Relay 1 Energise**
- 10.1.2 Relay 1 De-Energise**
- 10.1.3 Relay 1 Hold State**

Description

- Relay 1 energises when in fail condition
- Relay 1 de-energises when in fail condition
- Relay 1 holds state when in fail condition

Pr.10.2 Relay 2 Relay 2 Failsafe

	Distance	Level	Volume	Pump	OCM	Differential
Default	Hold State	Hold State	Hold State	De-Energise	Hold State	Hold State

Options displayed

- 10.2.1 Relay 2 Energise**
- 10.2.2 Relay 2 De-Energise**
- 10.2.3 Relay 2 Hold State**

Description

- Relay 2 energises when in fail condition
- Relay 2 de-energises when in fail condition
- Relay 2 holds state when in fail condition

Pr.10.3 Relay 3 Relay 3 Failsafe (D = Hold State)Options displayed

- 10.3.1 Relay 3 Energise**
- 10.3.2 Relay 3 De-Energise**
- 10.3.3 Relay 3 Hold State**

- Relay 3 energises when in fail condition
- Relay 3 de-energises when in fail condition
- Relay 3 holds state when in fail condition

NOTE: Relay designated LOSS-OF-ECHO will always de-energise on failsafe.
Relay 3 Failsafe is not applicable in differential or OCM mode.

Pr.10.4 Fail Time Failsafe time delay

	Distance	Level	Volume	Pump	OCM	Differential
Default	600	600	600	30	30	600

Enter time delay value (in seconds) before unit goes to selected failsafe positions. Minimum value is 30 seconds. Maximum Value is 9999 seconds.

Pr.10.5 mA Fail Analogue and Display Failsafe (Pump D = High)
(Other applications D = Hold)Options displayed

- 10.5.1 Analogue Low**
- 10.5.2 Analogue High**
- 10.5.3 Analogue Hold**

Description

- Set analogue output low
- Set analogue output high
- Analogue output holds its value

Analogue**Pr.11.1 Analog. O/P** Analogue Output (D = 4-20mA)

<u>Options displayed</u>	<u>Description</u>
11.1.1 Output 4-20mA	} related to span (Pr.3.0) or Pr.11.4.2
11.1.2 Output 20-4mA	
11.1.3 Output 0-20mA	
11.1.4 Output 20-0mA	
11.1.5 4-20mA Overrange	} will over-range 0-24mA if normal span (Pr.3.0) is exceeded
11.1.6 0-20mA Overrange	

The output represents different variables depending on the application mode selected at Pr.1.0.

Limits are defined by Pr.3.0

Pr. 1 Application	Output Proportional To
Distance Measurement	Target distance
Level Measurement	Level
Volume Measurement	Volume
Pump Control	Level
Open Channel Meter (OCM)	a) If 11.2.1 Output relative to Flow b) If 11.2.2 Output relative to Head
Differential Level Measurement (DLD)	Differential level. (The unit can differentiate between positive and negative differentials. (See Pr.11.2)

NOTE: Refer to Pr.11.3 for the mA output test.

Pr.11.2 Analog. Val Analogue value options (Only available in differential level measurement and OCM).

In differential mode (D = Upstream Level)

<u>Options displayed</u>	<u>Description</u>
11.2.1 Output differential of levels -	Pr.3.0 represents maximum differential in levels
11.2.2 Output upstream level -	Pr.3.0 represents the difference between upstream empty distance Pr.2.0 and maximum upstream level
11.2.3 Output downstream level -	Pr.3.0 represents the difference between downstream empty distance Pr.2.0 and maximum downstream level

In OCM mode (D = Relative to flow)

<u>Options displayed</u>	<u>Description</u>
11.2.1 Output relative to Flow	Output proportional to calculated flow
11.2.2 Output relative to Head	Output proportional to measured head (depth of liquid)

Pr.11.3 Test mA (D = 4mA)

This parameter outputs a mA value selected by the user. A value of 4, 8, 12, 16 or 20mA can be outputted and measured at terminals 12 & 13, to test the external circuitry. Display 11.3.* then press ENT to show 'Analogue Testing *mA'

Options displayed

- 11.3.1 Analogue set output 4mA
- 11.3.2 Analogue set output 8mA
- 11.3.3 Analogue set output 12mA
- 11.3.4 Analogue set output 16mA
- 11.3.5 Analogue set output 20mA
- 11.3.6 End analogue test

Description

- Sets the analogue output to 4mA
- Sets the analogue output to 8mA
- Sets the analogue output to 12mA
- Sets the analogue output to 16mA
- Sets the analogue output to 20mA
- Exits analogue test

Pr.11.4 Analogue Scale**11.4.1 Analogue Datum** (D = 0.000)

If an analogue output is required with a zero different from the measurement zero (Pr.2.0) then an offset defined as a percentage of the measurement span/flow/volume etc., can be entered here.

11.4.2 Analogue Span (D = 100.0)

If an analogue output is required with a span different to that defined for the measurement (Pr.3.0) then an alternative value defined as a percentage of the measurement span/flow/volume etc., can be entered here. A value of zero is ignored.

Miscellaneous**Pr.12.1 Offset** (D = 0.00)

Both negative and positive values can be input. This value must be entered in metres.

This parameter has two uses:

1. It can be used to correct minor reading errors on the display
2. It can be used to prevent loss-of-echo when the target can go further away from the transducer than the desired span.
 - e.g. a) When a channel floor is lower than the zero point of a "V" notch weir.
 - b) To set an elevated zero level in a vessel, which is not normally completely emptied.

Add the extra depth to Pr.2.0 and enter minus the extra depth at Pr.12.1 in metres.

Pr.12.2 Passcode Security Code Store

A new security code can be entered at this parameter, but after entry it is scrambled. Refer to Hycontrol if you forget your security code, and quote the number displayed.

Pr.12.3 NoOfDecimal Number of decimal places (D = 2 dec points)

The number of decimal places required for displaying when in normal operation.

<u>Options displayed</u>	<u>Description</u>
12.3.1 Display No decimal point	Display value with no decimal point
12.3.2 Display 1 Decimal Point	Display value with 1 decimal point
12.3.3 Display 2 Decimal Points	Display value with 2 decimal points
12.3.4 Display 3 Decimal Points	Display value with 3 decimal points

Pr.12.4 Relay tot. Relay totaliser (D = Off)

<u>Options displayed</u>	<u>Description</u>
12.4.1 Relay totaliser off	Disables relay totaliser function
12.4.2 Relay totaliser on	Enable relay totaliser function

Pr.12.5 Simulation (D = No)

<u>Options displayed</u>	<u>Description</u>
12.5.1 Simulation No	Don't simulate program
12.5.2 Simulation Yes	Start simulation

The value displayed will depend on the application set in Pr.1.0.
Select **12.5.2 Simulation Yes** to simulate the operation of the instrument as set up between Blanking (Pr.4.0) and Empty distance (Pr.2.0).

<u>Application type</u>	<u>Display value relative to</u>
Level Measurement	- LEVEL
Distance measurement	- DISTANCE
Differential level measurement	- NO SIMULATION AVAILABLE
Open Channel Measurement	- LEVEL / FLOW
Pump Control	- LEVEL
Volume	- LEVEL

It will set all LEDs/relays and the current output as programmed. Therefore, care must be taken if the instrument is wired into other instruments or controls. The displayed value, on which all relays are operated, is that which is set by the operator.

The initial speed of the simulation is that set into Rate of Change (Pr.5.0) this can be increased by a factor of 2 by pressing the '↻' key and the key can be pressed 6 times (x64). To reduce the speed press the '⏪' key, the speed cannot be reduced below that defined by Rate of Change.

The direction of the simulation can be changed by using the '↑' and 'ENT' keys, which one has to be pressed depends on the set up. Press 'M' twice to end.

Pr.12.6 Station ID (D = 1)

For polled data transfer, the unit must have a station number assigned to it in the range of 1 – 31, which must be unique to the unit.

<u>Text displayed</u>	<u>Description</u>
12.6.1 StationID 01	Unique identification number for instrument

Pr.12.7 Sync Instrs Synchronise instruments (D = Master)Options displayed

12.7.1 Sync Master

12.7.2 Sync Slave

This parameter is used in conjunction with Pr12.6 Station ID for synchronising two or more instruments when they are in close proximity. See Appendix 6 for details, Pg 64.

Pr.12.8 Check Search (D = Off)Options displayed

12.8.1 Check Search Off

12.8.2 Check Search On

Description

Check search not used

Check search included

Check search should be used where fill rates can sometimes be greater than that entered at Pr.5.0, or if the transducer is liable to be submerged.

Pr.12.9 Maximum gain (D = 100.0)

The maximum gain will be displayed in % and will be linear. It defines the level of gain (power) available to the instrument when searching for a valid echo.

Pr.12.10 Serial Number (Viewable only)

This parameter displays the serial number of the Miniflex LR unit.

Pr.12.11 Revision Number (Viewable only)

Displays the Revision number of the software, e.g. LR 1.11.

Pr.12.12 Echo Velocity (D = 344.1 i.e. speed of sound in air at 20°C)

If operating through any medium other than air enter the velocity of sound through that medium in metres per second.

Pr.12.13 Gain Control (D = Fixed for OCM, D = Variable for All other applications)Options displayed

12.12.1 Gain control variable

12.13.2 Gain control fixed

Description

Variable gain selection

Fixed gain selection

When in OCM select variable gain if instrument locks on to a protruding object, which is closer to the transducer than the actual target.

Pr.12.14 Transducer (D = 12.14.1 Trans R*TK15-ATEX)Options displayed

12.14.1 Trans R*TK15-ATEX

12.14.2 Trans R*TK15

Description

ATEX certified transducer


Non-ATEX certified transducer

MINIFLEX LR DEFAULT PROGRAMS

For each application type in the Miniflex LR there is a default program, which is automatically loaded on first selecting a new application at Pr.1.0. Resetting the instrument (Page 13) will load the factory default program for a typical distance measurement application. The default settings for all 6 application types are detailed on the following pages.

DISTANCE – Distance Measurement Mode Default Program

Changing the application to Distance Measurement or resetting the instrument, loads this distance measurement default program into memory.



This default program is created to do the following:-

To measure and display the distance between the face of the transducer and the target in metres.

Maximum distance of 10.00m.

Rate of change of 10.0 metre/min.

No alarms.

4-20mA output proportional to distance.


This program can be easily modified to suit the required application. You should delete from this program any unwanted entries (e.g. 8.3.4 Relay 3 L.O.E.).

Parameter number	Default Setting	Description
2.0 Empty Distance	= 10.00	Maximum measurable distance from transducer.
3.0 Operational Span	= 10.00	The span, based on zero level.
4.0 Blanking	= 0.500	Blanking zone into which target should not rise.
5.0 RateOfChange	= 10.00	The maximum rate of change of target distance in metres/minute.
8.1 Rly1 Options	= 8.1.5 Relay 1 Off	Relay 1 Off
8.2 Rly2 Options	= 8.2.5 Relay 2 Off	Relay 2 Off
8.3 Rly3 Options	= 8.3.4 Relay 3 L.O.E.	Relay 3 (L.O.E. Alarm – de-energises relay)
10.4 Fail Time	= 600	Failsafe time in seconds
10.5 mA Fail	= 10.5.3 Analogue Hold	Analogue output holds on failsafe.
11.1 Analog O/P	= 11.1.1 Output 4–20mA	4-20mA output fixed to span (Pr.3.0)
12.14 Transducer	= 12.14.1 Trans R*TK15-ATEX	Relevant only for temperature compensation

To simulate the program go to 12.5.2 *yes* then press ENT again.

LEVEL – Level Measurement Mode Default Program

Changing the application to Level measurement loads this default program into memory.



This default program is created to do the following:-

To measure and display the level of liquid in metres.

Maximum level 5.5m.

Fill rate 1.0 metre/min.

Alarm if level exceeds 5.0 metres or goes below 1m.

4-20mA output proportional to level.


This program can be easily modified to suit the required application. You should delete from the program any unwanted entries (e.g. Relay 2 settings).

Parameter number	Default Setting	Description
2.0 Empty Distance	= 6.000	Distance from transducer to zero level.
3.0 Operational Span	= 5.500	The span, based on zero level.
4.0 Blanking	= 0.500	Blanking zone into which level should not rise.
5.0 RateOfChange	= 1.000	The maximum rate of change of liquid level in metres/minute.
8.1 Rly1 Options	= 8.1.1 Relay 1 Norm-Energised	Relay 1 to alarm on level (normally energised)
8.1.1.1 Relay 1 Set	= 5.0	Relay 1 to de-energise at 5.0 metres to indicate high alarm.
8.1.1.2 Relay 1 Reset	= 4.8	Relay 1 to re-energise at 4.8 metres to clear the high alarm.
8.2 Rly2 Options	= 8.2.1 Relay 2 Norm-Energised	Relay 2 to alarm on level (normally energised)
8.2.1.1 Relay 2 Set	= 1.0	Relay 2 to de-energise at 1.0 metre to indicate low alarm.
8.2.1.2 Relay 2 Reset	= 1.2	Relay 2 to re-energise at 1.2 metres to clear the low alarm.
8.3 Rly3 Options	= 8.3.4 Relay 3 L.O.E.	Alarm Relay 3 (L.O.E. Alarm – de-energises relay)
10.1 Relay 1	= 10.1.3 Relay 1 Hold State	Hold alarm indication (relay 1) on failsafe.
10.2 Relay 2	= 10.2.3 Relay 2 Hold State	Hold alarm indication (relay 2) on failsafe.
10.4 Fail Time	= 600	Failsafe time in seconds
10.5 mA Fail	= 10.5.3 Analogue Hold	Analogue output holds on failsafe.
11.1 Analog O/P	= 11.1.1 Output 4–20mA	4-20mA output fixed to span (Pr.3.0).
12.14 Transducer	= 12.14.1 Trans R*TK15-ATEX	Relevant only for temperature compensation

To simulate the program go to *I2.5.2* yes then press ENT again.

VOLUME - Contents Measurement with Volumetric Conversion Default Program

Changing the application to volume measurement loads this default program into memory.



This default program is created to do the following:-

To measure the level in a flat bottomed tank. Dimensions as shown.

Output/display in m³.

Analogue output to be 4-20mA proportional to volume in tank.

High alarm at 90% volume.

Low alarm at 10% volume.


This program can be easily modified to suit the required application. You should delete from this program any unwanted entries (e.g. Relay 3 L.O.E.).

Parameter number	Default Setting	Description
2.0 Empty Distance	= 6.000	Distance from transducer to zero level.
3.0 Operational Span	= 5.500	The span, based on zero level.
4.0 Blanking	= 0.500	Blanking zone into which level should not rise.
5.0 RateOfChange	= 1.000	The maximum rate of change of liquid level in metres/minute.
6.1 Vessel Shape	= 6.1.1 Linear Vessel	Define vessel as linear vessel
6.2 Display Units	= 6.2.7 Units %	Display in %
8.1 Rly1 Options	= 8.1.1 Relay 1 Norm-Energised	Relay 1 to alarm on volume (normally energised)
8.1.1.1 Relay 1 Set	= 90	Relay 1 to de-energise at 90% to indicate high alarm.
8.1.1.2 Relay 1 Reset	= 85	Relay 1 to re-energise at 85% to clear the high alarm.
8.2 Rly2 Options	= 8.2.1 Relay 2 Norm-Energised	Relay 2 to alarm on volume (normally energised)
8.2.1.1 Relay 2 Set	= 10	Relay 2 to de-energise at 10% to indicate low alarm.
8.2.1.2 Relay 2 Reset	= 15	Relay 2 to re-energise at 15% to clear the low alarm.
8.3 Rly3 Options	= 8.3.4 Relay 3 L.O.E. Alarm	Relay 3 (L.O.E. Alarm)
12.14 Transducer	= 12.14.1 Trans R*TK15-ATEX	Relevant only for temperature compensation

To simulate the program go to 12.5.2 *yes* then press ENT again.

Pump Control Default Program

Changing the application to Pump Control loads this default program into memory.



This default program is created to do the following:

- 2 pump control, pump down in a wet-well, duty-assist operation.
- Alternate pump duty to reduce wear.
- 4-20mA to remote indicator.
- Loss-of-Echo indication to telemetry.
- Display actual level in metres.


This program can be easily modified to suit the required application. You should delete from this program any unwanted entries (e.g. 9.2.1 Duty assist).

Parameter number	Default Setting	Description
2.0 Empty Distance	= 6.000	Distance from transducer to zero level.
3.0 Operational Span	= 5.500	The span, over which measurement is required.
4.0 Blanking	= 0.500	Blanking zone into which level should not rise.
5.0 RateOfChange	= 1.000	The maximum rate of change of liquid level in metres/minute.
8.1 Rly1 Options	= 8.1.2 Relay 1 Norm-DeEnergised	Relay 1 control on level (normally de-energised)
8.1.1.1 Relay 1 Set	= 1.0	Relay 1 energises at 1.0m to turn pump 1 on.
8.1.1.2 Relay 1 Reset	= 0.5	Relay 1 de-energises at 0.5m to turn pump off.
8.2 Rly2 Options	= 8.2.2 Relay 2 Norm-DeEnergised	Relay 2 to control on level (normally de-energised)
8.2.1.1 Relay 2 Set	= 2.0	Relay 2 energises at 2m to turn pump 2 on.
8.2.1.2 Relay 2 Reset	= 0.5	Relay 2 de-energises at 0.5m to turn pump 2 off.
8.3 Rly3 Options	= 8.3.4 Relay 3 L.O.E. Alarm	Relay 3 (L.O.E. Alarm – de-energises relay)
9.1 Pump Sequence	= 9.1.2 Alternate pumps 1 & 2	Alternate pumps 1 & 2
9.2 Duty Standby	= 9.2.1 Duty Assist	Duty assist operation.
10.1 Relay 1	= 10.1.2 Relay 1 De-Energise	Pump 1 de-energise on failsafe.
10.2 Relay 2	= 10.2.2 Relay 2 De-Energise	Pump 2 de-energise on failsafe.
10.4 Fail Time	= 30	Failsafe time in seconds
10.5 mA Fail	= 10.5.2 Analogue High	Analogue output goes high on failsafe.
11.1 Analogue O/P	= 11.1.1 Output 4–20mA	4-20mA output fixed to span (Pr.4).
12.14 Transducer	= 12.14.1 Trans R*TK15-ATEX	Relevant only for temperature compensation

To simulate the program go to *I2.5.2* yes then press ENT again.

OpenChannel Flowmeter Default Program

Changing the application to Open Channel Flow Monitoring loads this default program into memory.



This default program is created to do the following:-

Standard Ratio Rectangular flume, with a maximum flow of 50 litres per second at head 28cm.

Loss-of-Echo indication to telemetry system.

4-20mA output proportional to flow.

Totalise flow and provide pulsed output to external totaliser every 1000 litres.

Display flow reading.

This program can be easily modified to suit the required application. You should delete from this program any unwanted entries (e.g. Relay 1 settings).

Parameter number	Default Setting	Description
2.0 Empty Distance	= 1.200	Distance from transducer to bottom of channel.
3.0 Operational Span	= 0.280	Level at which maximum flow rate value is defined.
4.0 Blanking	= 0.500	Blanking zone into which level will not rise. It is suggested that this is above the top of the channel to allow the system to continue reading up to that level.
5.0 RateOf Change	= 1.000	Rate of change of level 1m/min.
7.1 Flow device	= 7.1.1 Std. Ratio Rect. Flume 3/2	To define that a rectangular flume is being used (Not BS3680).
7.3 Maximum Flow	= 50	Defines the maximum flow is 50 litres per second.
7.6 Totaliser Units	= 7.6.2 Totalise In m3	To avoid totaliser overflow, totalise in cubic metres
7.7 Ext.Tot.Drv	= 7.7.1 = 1.000	External totaliser in cubic metres
8.1 Rly1 Options	= 8.1.6 Flow alarm	Relay 1 to alarm on flow (normally energised)

SECTION 4

8.1.1.1 Relay 1 Set	= 45	Relay 1 to de-energise at 45 litres per second to indicate flow alarm.
8.1.1.2 Relay 1 Reset	= 40	Relay 1 to re-energise at 40 litres per second to clear the flow alarm.
8.2 Rly2 Options	= 8.2.4 Relay 2 L.O.E. Alarm	Relay 2 (L.O.E. Alarm)
8.3 Rly3 Options	= 8.3.6 Relay 3 Totaliser Output	Relay 3 used to trigger external totaliser
10.1 Relay 1	= 10.1.2 Relay 1 De-Energise	De-energise (relay 1) on failsafe.
10.2 Relay 2	= 10.2.2 Relay 2 De-Energise	De-energise (relay 2) on failsafe.
10.4 Fail Time	= 30	Failsafe time in seconds
10.5 mA Fail	= 10.5.3 Analogue Hold	Analogue output holds on failsafe.
11.1 Analog. O/P	= 11.1.1 Output 4–20mA	Output over 4-20mA
11.2 Analog. Val	= 11.2.1 Output relative to flow	4-20mA output is proportional to flow
12.14 Transducer	= 12.14.1 Trans R*TK15-ATEX	Relevant only for temperature compensation


To simulate the program go to *12.5.2* *yes* then press ENT again.
(NOTE:- Simulates the level / flow).

To clear and initiate the totaliser before returning to run mode set 7.8 Total. Reset = 7.8.2 Totaliser Reset Yes

Differential Level Measurement Program

Changing the application to Differential Level Measurement Control loads this default program into memory. In this mode, the transceiver drives two transducers to measure the difference in levels by subtracting the downstream level from the upstream level. Please see connection diagram Figure 7 for transducer wiring (Page 8).

The upstream transducer should be chosen to give a positive differential value.



This default program is created to do the following:-

- Start rake when differential reaches 0.15m.
- Stop rake when differential falls to 0.05m.
- Maximum differential 0.50m.
- Alarm if level on upstream side exceeds 0.60m.
- 4-20mA output proportional to differential.
- On Loss-of-Echo energise alarm and switch rake on.

This program can be easily modified to suit the required application. You should delete from this program any unwanted entries (e.g. Relay 2 settings).

Parameter number	Default Setting	Description
2.0 Empty Distance	= 2.000	The distance from bottom of channel to transducers in metres.
3.0 Operational Span	= 0.500	The maximum differential span.
4.0 Blanking	= 0.500	Blanking zone.
5.0 RateOfChange	= 1.000	The maximum rate of change of level in metres/minute.
8.1 Rly1 Options	= 8.1.2 Relay 1 Differ. Control	Relay 1 designated for differential control.
8.1.1.1 Relay 1 Set	= 0.15	Relay 1 energises at differential 0.15m to start rake.
8.1.1.2 Relay 1 Reset	= 0.05	Relay 1 de-energises at differential 0.05m to stop rake.
8.2 Rly2 Options	= 8.2.7 Relay 2 Upstream Alarm	Relay 2 to alarm on an upstream level.
8.2.1.1 Relay 2 Set	= 0.60	Relay 2 de-energises at 0.60m high alarm.
8.2.1.2 Relay 2 Reset	= 0.55	Relay 2 energises at 0.55m to clear high alarm.
10.1 Relay 1	= 10.1.1 Relay 1 Energise	Switch rake on in failsafe.
10.2 Relay 2	= 10.2.2 Relay 2 De-Energise	Alarm level indication on failsafe.

SECTION 4

10.4 Fail Time	= 600	Failsafe time in seconds
10.5 mA Fail	= 10.5.3 Analogue Hold	Analogue output holds on failsafe.
11.1 Analog O/P	= 11.1.1 Output 4–20mA	4-20mA output fixed to span (Pr.3.0).
11.2 Analog.Val	= 11.2.1 Differential	Proportional to the differential
12.4 Relay tot.	= 12.4.2 Relay totaliser On	This counts the number of times the rake is turned on, and how many hours it has been energised.
12.14 Transducer	= 12.14.1 Trans R*TK15-ATEX	Relevant only for temperature compensation

NOTE:- It is not possible to simulate any differential mode applications.

COMMISSIONING FAULT FINDING

WARNING! FAULT FINDING SHOULD BE UNDERTAKEN ONLY BY SUITABLY TRAINED PERSONNEL.

Basic Hardware**A) The display is blank or frozen, the leds are unlit and the neon does not fire:-**

1. Ensure that power is being supplied to the board, and that it is correctly wired. Refer to figure 3, on Page 3.
2. Check fuses F3 (ac) and F4 (dc)
3. Check that the supply voltage is within specified levels (See Section 1 Page 3). A large voltage drop can cause the unit to lock and show last distance or level reading.

B) The fuse blows continuously:-

1. Power down and fit a new fuse – refer to Page 3
Remove all connection blocks except AC power TB6 or DC power TB1.
If fuse does not blow on power up insert each terminal block until fault reappears.
Check wiring of this terminal block.
2. Check that the power supply is within specified limits -refer to Page 3.
3. Check the enclosure for metal debris which may be under the lower PCB.

C) The system powers up, but displays garbage:-

1. Power down then check that an EPROM is fitted at U2 and that it is firmly in place.

D) The display is blank:-

1. Power down then check that a jumper link is fitted on 3 pin link LK1 at the side of the display on the top PCB going between the centre pin and pin W.

E) The display appears faded or too dark:-

1. Adjust contrast pot P1.

F) The display shows 'LOSS OF ECHO':-

1. Check the transducer wiring and connections to the instrument. Note that different connections are used if a temperature compensated transducer is connected. See Figure 3, Page 3, and Page 4.

If the transducer cable has been extended as per Page 8, disconnect and remove the transducer and connect it direct to the Miniflex LR. If the unit now operates, recheck the extension cable connections and routing, avoiding power cables. Re-install the transducer checking that its aim is perpendicular to the target surface.

2. Check whether the neon light on the bottom PCB nearest terminal 1 is flashing. If it is proceed to number 3, if it is not then:-
 - a: Disconnect the transducer: If the neon now lights then there is a short circuit in the cabling.
 - b: If the neon does not light the transmission fuse may have blown. Check F1 T80mA fuse on the bottom PCB.
 - c: If the unit still shows 'LOSS OF ECHO' check that you can hear the transducer "clicking" when close to the ear.
 - d: If the transducer does not click proceed to 5.
3. Is there a target within the empty distance specified in Pr.2.0? This is particularly important if temperature variations are experienced and no compensation is applied.
4. Is the vessel empty with a conical, parabolic, sloping or spherical bottom? This commonly causes loss of echo if the transducer cannot be mounted over the centre of the vessel. When the vessel becomes empty the pulse from the transducer hits the sloping sides of the bottom section and the signal is not reflected back to the transducer. Under this condition the display will indicate 'LOSS OF ECHO' but the failsafe designation will operate until product returns and the system will automatically recover and track level. If the transducer cannot be mounted centrally, the problem may be overcome by the installation of a target plate.
5. Connect a known good transducer to the instrument and check the operation. If the known transducer gives a good signal check the instrument's gain by pressing the 'G' key. The number displayed ranges from 0.1 – 100, the lower the number the greater the signal strength.

If the gain figure is 50 - 100 check the surface level for foam or other materials which may float in and out of the beam and cause poor echoes.

G) The keypad fails to respond:-

1. Check for correct alignment of connection from keypad to main board.
2. Check that key press sequence is valid; refer to Page 11.
3. Power down unit and wait 5 seconds. Power up and immediately press 'M'. This should result in 'Program Mode' being displayed. It is now advisable to reset to your original default program, Page 15.

H) Analogue output is unstable:-

1. Connect a test meter in series with your external wiring.
Can the fault be seen on the test meter? If YES, then use Pr.11.3 to set a stable value into the current loop.
If the output is still unstable disconnect external wiring and connect a meter across terminals 12 and 13 and repeat Pr.11.3 test.
If the output is now stable check wiring and meters

I) Analogue has no output:-

1. Check programme value at Pr.11.1
2. Insert a test meter in series with the output. Under Pr.11.3 select a fixed output. If still no output, connect a test meter directly across terminals 12 and 13, repeat test under Pr.11.3. If no value is read at terminals 12 to 13 contact Hycontrol.

J) Analogue output is less than 20 at maximum display reading:-

1. The load attached to the output may be too high. To check this disconnect all the external wiring and see if it now reads 20. The output is capable of driving 20mA into 750 Ohms.

K) Analogue output does not correspond to application:-

1. Check that the correct options (Pr.11.1, 11.2 and 11.4) have been selected.
2. Check that the correct span (Pr.3.0) has been input, this is the value over which the analogue will be spanned unless a separate entry has been made at Pr.11.4.1 and 11.4.2.

L) Reading on display and outputs stay high:-

- * This is usually caused by return echoes from close-in obstructions.
- 1. Check for obstructions. If the transducer is mounted on a standpipe, check for rough edges at the connection with the vessel, refer to figure 6 Page 7.
- 2. If there are no close-in obstructions ensure that the isolation kit is fitted on the transducer and that the transducer is mounted correctly. The isolation kit should enable the transducer to move slightly, it should not be solid. (Not applicable to flanged transducers.)
- 3. Check the entry at Pr.4.0, Blanking distance, and return it to 0.5m if reduced from factory setting
- 4. May be caused by rate of change, Pr.5.0 being too small.

M) Reading is lower than expected:-

- 1. Check that Pr.2.0 and Pr.3.0 are correct for the application
- 2. It can be caused when the level rises into the blanking zone. The system can then lock on to a multiple echo, and may continue tracking the multiple when the level decreases. Using check search Pr.12.8 should rectify this situation, but preventing the level entering the blanking zone is the preferred solution.
- 3. It can also be caused by the level moving at a much faster rate than is allowed for by the defined rate of change (Pr.5.0). To solve the problem the rate of change value should be increased to more closely match the real rate.

N) Reading changes in steps:-

- * This is usually caused by the rate of change value (Pr.5.0) being too small to keep up with the process.
- 1. To rectify, increase the value of Pr.5.0 to match the rate of change of level.

O) The display is inaccurate:-

- 1. The empty distance (Pr.3.0) of the vessel may be incorrectly set.
- 2. The dimensions of the vessel or flume may be incorrect, as may the values of maximum flow, volume or mass conversion.
- 3. The system may require temperature compensation.
- 4. The application may include vapours that significantly change the speed of sound.

P) Temperature compensation error:-

1. The position of the transducer is important to prevent heating by sunlight and convection currents. Also the transducer should be in a free-air vented position if possible to prevent hot-spots.

NOTE: The transducer sensor compensates only for temperature variance, it is not expected to accurately measure the actual temperature.

Q) Temperature reads 20°C all the time:-

1. Check the transducer wiring and connections to the instrument. Note that different connections are used if a temperature compensated transducer is connected. See Figure 3, Page 3, and Page 4.
Also check transducer selection at Pr.12.14, Page 34
2. Check fuse F2 T80mA.

R) The boards hums loudly:-

- * Usually vibration from the transformer.
1. Check the mounting screws for tightness.

S) Relays not switching:-

1. Check the programmed relay designations and settings at Pr.8.1 - Pr.8.3
Functions can be tested under simulation using Pr.12.5 (Not differential).
2. Check contact continuity at the terminals 14 - 22.

WARNING: It is recommended that all external controls, alarms etc. are disconnected before performing the above tests.

LINEARISATION VESSELS OR FLUMES

This feature allows volume conversion to be applied to irregular shaped vessels and flow measurements to be made on open channels, providing that level/volume/flow relationships are known.

The system allows the entry of a volume or flow profile with up to 24 points of level or head to be entered into memory, that is then used to produce the required flow or volume values when in 'RUN' mode.

Before proceeding it is useful to write down a table of the point numbers and 'Level / Head in Metres' with the corresponding '%Volume / % Flow' values, to facilitate programming.

VOLUME


The custom volume table is selected in Pr.6.1.8, Page 18. The profile is level in metres, against percentage of the total volume. See example on page 52.

FLOW

The custom flow table is selected in Pr.7.1.8, Page 20. The profile is stored as head in metres, against percentage of the total flow. See example on page 50.

PROCEDURE

The procedure uses a 24 point curve to map the profile, but all 24 points do not have to be used.



The profile data are input into Pr.6.1.8 for volume and Pr.7.1.8 for flow. The values can be displayed and changed as required.

Custom table - Keyboard controls

- ↑** - Used to increase digit and change value.
- ↶** - Moves to previous entered value if available.
- ↷** - Move to next digit.
- ENT** - Enters a new value and moves to next entry if available.
- M** - Exit custom table key, asks for confirmation of storing table before returning the operator to normal program.

Custom table - Inputting Values

When inputting a value for the first time or after a reset the initial value will be displayed as `__ . ___` or `___ . __`.

Selecting either the '↑' or '↷' will display 0.000 allowing you then to enter the head or level in metres. The decimal position is fixed and cannot be changed.

For volume, both Level (Metres) and Volume (%) figures should be entered up to the required number of points you wish to map.

For flow, both Head (Metres) and Flow (%) figures should be entered up to the required number of points you wish to map.

After entering each value, press the **ENT** key to accept the value and display the next point to be entered.

To finish entering the data points press the **M** key.

PARAMETER RESET: CLEARS ALL METRES VALUES TO `__ . ___`

Head / Level (Metres)

The decimal position is fixed at 3 decimal places

The allowable range of level / head values is 0.000 – 9.999m

PARAMETER RESET: CLEARS ALL % VALUES TO `__ . __`

Flow / Volume (%)

The decimal position is fixed at 1 decimal place.

The allowable range of % values is 0-250%.

Any unused data values **must** be cleared to `__ . ___`


- NOTE:**
1. The standard keypad time-outs are suspended, to allow sufficient time to enter the data.
 2. We recommend that the required values are written in tabular form, as shown, before programming commences.

Example: Flow – Special Flume Mapping

Use default flow example on Page 39, but substitute a special 'U' throat flume with maximum flow 50 litres/second at 30 cm/head.

First, create the following table from the relationship of head and flow, which must be given for the special flume.

Point	Head (m)	Flow litres/sec	% Flow
1	0.000	0.0	000.0
2	0.025	0.6	001.1
3	0.050	2.2	004.4
4	0.075	4.8	009.5
5	0.100	8.1	016.2
6	0.150	16.3	032.5
7	0.200	26.0	052.0
8	0.250	37.5	075.0
9	0.300	50.0	100.0
10	-.----	Not used	----. -
11	-.----	Not used	----. -
12	-.----	Not used	----. -




21	-.----	Not used	----. -
22	-.----	Not used	----. -
23	-.----	Not used	----. -
24	-.----	Not used	----. -


NOTE: Points 10 to 24 not used - leave at factory default value.

Now continue programming the instrument as follows:

Flowchart to program the example custom flow table into the instrument.



Example: Vessel Mapping



Required values

Use the custom table to create a volume profile for a non- standard tank with a capacity of 8500 litres. Each of the points is entered as a Level in metres against % Volume.

Point	Level (m)	Volume in Units	% Volume
1	0.000	0	000.0
2	0.500	0	000.0
3	1.000	612	007.2
4	1.500	1368.5	016.1
5	2.000	2320.5	027.3
6	2.500	3187.5	037.5
7	3.000	4122.5	048.5
8	3.500	5057.5	059.5
9	4.000	5992.5	070.5
10	4.500	6800.0	080.0
11	5.000	7607.5	089.5
12	5.500	8500.0	100.0
13	--.---	Not used	----.---
14	--.---	Not used	----.---



23	--.---	Not used	----.---
24	--.---	Not used	----.---

NOTE: Points 13 to 24 not used - leave at factory default value.

Leave **Pr.6.2 DisplayUnits** at the default setting of **Litres** to display the readings in litres and change **Pr.6.3 MaxDsp x 100 = 85.0** to scale the 0 – 100% volume value 0 to 8500 litres.

SPECIFICATION**Transceiver**

Enclosure	: IP65, NEMA 4X, IK08 / IK07 polycarbonate, hinged lid.
Dimensions	: 185H X 213W X 119.5D (mm).
Weight	: 1.55Kg
Power Supply	: 95/110/230VAC \pm 10%. 50/60Hz, 12VA, 24V DC + 25% - 10%, 9W. Separate terminals.
Fuse Rating	: F3 T160mA for AC supply F4 T500mA for 24V DC supply F1 & F2 T80mA.
Range	: Up to 10 metres.
Accuracy of Change in Level	: \pm 0.25% of measured distance from the transducer at constant temperature of 20°C,
Ambient Temperature	: -20°C to + 70°C.
Resolution	: 2mm or 0.1% of range, whichever is the greater.
Analogue Output	: 4-20mA into 750 Ohms. 16 bit. Short circuit protected and opto-isolated on AC powered units. Not opto-isolated on 24V DC units.
Relay Outputs	: 3 multi-function SPDT relays rated 8A/250VAC/30V DC resistive, with gold contacts.
Indication	: Integral display, 2lines x 16digit Backlit LCD. 3 red LEDs to indicate relay status.
Interface	: 5 key integral keypad with security code.
Failsafe	: High, Low, Hold
Damping	: Fully adjustable
Blanking	: Fully adjustable


Transducer

Type	: RYVK15	RYTK15	RWVK15	RWTK15
Temperature Compensation	: No	Yes	No	Yes
Frequency (in KHz)	: 41.5 kHz	41.5 kHz	41.5 kHz	41.5 kHz
Beam Angle at 3dB	: 12 degrees @ -3dB	12 degrees @ -3dB	12 degrees @ -3dB	12 degrees @ -3dB
Body Material	: PVDF	PVDF	PVDF	PVDF
Face Material	: Glass reinforced epoxy	Glass reinforced epoxy	PVDF	PVDF
Process Temperature	: -40°C to + 90°C	-40°C to + 90°C	-40°C to + 90°C	-40°C to + 90°C
Protection	: IP68	IP68	IP68	IP68
Weight (Kg)	: 1.5	1.5	1.5	1.5
Hazardous area approval	: None	None	None	None

* Refer to pages 54 & 55 for ATEX transducers & installations.

Specifications & Installation Instructions for ATEX Transducers in Hazardous Areas

Applies to models:- RY*K15-ATEX & RW*K15-ATEX



The installation must be in accordance with the applicable codes of practice and harmonized standards for Ex mb (encapsulated) equipment.

The transducer must be driven only by one of the above listed transceivers.


The transceiver must always be installed in a safe area.

User repairs are not permitted; in case of faults return the unit to Hycontrol.

Periodically clean the radiating face only with clean water, and inspect the body and wiring for damage.

To avoid electrostatic hazard the equipment shall not be installed in a location where external conditions are conducive to the build-up of electrostatic charge on the non-metallic enclosure. The equipment shall be cleaned only with a damp cloth.

Specifications & Installation Instructions for ATEX Transducers in Hazardous Areas



Specifications

Type; RYVK15-ATEX
RYTK15-ATEX (T/comp)
Frequency: 41.5 kHz
Beam angle: 14° @ -3dB
Body material: PVDF
Face material: Glass reinforced epoxy
Temp. range: -40°C to +60°C
Range: Up to 10 metres

Typical marking

Manufacturer: Hycontrol Ltd.
CE marking /
Notified body: 0038
Group / category; II 2 G
Ex mb IIC T6 Gb

EC certification: Sira 14ATEX5083X
Type: RYVK15-ATEX
RYTK15-ATEX
Tamb: -40°C to +60°C
Protection: IP68
S/No: xxxxxxxxxxxxxxxx
Mfg. year: xxxx

Specifications

Type; RWVK15-ATEX
RWTK15-ATEX (T/comp)
Frequency: 41.5 kHz
Beam angle: 14° @ -3dB
Body material: PVDF
Face material: PVDF
Temp. range: -40°C to +60°C
Range: Up to 10 metres

Typical marking

Manufacturer: Hycontrol Ltd.
CE marking /
Notified body: 0038
Group / category; II 2 GD
Ex mb IIC T6 Gb
Ex mb IIIC T85°C Db

EC certification: Sira 14ATEX5083X
Type: RWVK15-ATEX
RWTK15-ATEX
Tamb: -40°C to +60°C
Protection: IP68
S/No: xxxxxxxxxxxxxxxx
Mfg. year: xxxx

DISTANCE APPLICATION PARAMETERS				
Pr	Description	Factory Default	User	Service
Application				
1.0	Basic Application	Distance		
Basic Set-up				
2.0	Empty Distance	10.00		
3.0	Operational Span	10.00		
4.0	Blanking	0.500		
5.0	RateOfChange	10.00		
Relays				
8.1	Rly1 Options	Off		
8.1.1.1	R1 Set	NOT APPLICABLE		
8.1.1.2	R1 Reset	NOT APPLICABLE		
8.2	Rly2 Options	Off		
8.2.1.1	R2 Set	NOT APPLICABLE		
8.2.1.2	R2 Reset	NOT APPLICABLE		
8.3	Rly3 Options	L.O.E. Alarm		
8.3.1.1	R3 Set	NOT APPLICABLE		
8.3.1.2	R3 Reset	NOT APPLICABLE		
Failsafe				
10.1	Relay 1	NOT APPLICABLE		
10.2	Relay 2	NOT APPLICABLE		
10.3	Relay 3	De-Energise		
10.4	Fail Time	600		
10.5	mA Fail	Hold		
Analogue				
11.1	Analogue O/P	Output 4-20mA		
11.2	Analogue Value	NOT APPLICABLE		
11.3	Test mA	4mA		
11.4	Analogue Scale	NO VALUE REQUIRED		
11.4.1	Datum (%)	0.0		
11.4.2	Span (%)	100.0		
Miscellaneous				
12.1	Offset	0.000		
12.2	Passcode	36.67		
12.3	NoOfDecimal	2 Dec Points		
12.4	Relay tot.	Off		
12.5	Simulation	No		
12.6	Station ID	1		
12.7	Sync Instrs	Master		
12.8	Check Search	Off		
12.9	Maximum gain	100.0		
12.10	Serial Number Store	Serial Number		
12.11	Rev. Number Store	Revision Number		
12.12	Echo Velocity	344.1		
12.13	Gain Control	Variable		
12.14	Transducer	R*TK15-ATEX		

NOT APPLICABLE – Parameter is not required for the selected option but may need to be set if the option is change

NO VALUE REQUIRED – This parameter is just a heading and leads to another parameter.

LEVEL APPLICATION PARAMETERS				
Pr	Description	Factory Default	User	Service
Application				
1.0	Basic Application	Level		
Basic Set-up				
2.0	Empty Distance	6.000		
3.0	Operational Span	5.500		
4.0	Blanking	0.500		
5.0	RateOfChange	1.000		
Relays				
8.1	Rly1 Options	Norm-Energised		
8.1.1.1	R1 Set	5.000		
8.1.1.2	R1 Reset	4.800		
8.2	Rly2 Options	Norm-Energised		
8.2.1.1	R2 Set	1.000		
8.2.1.2	R2 Reset	1.200		
8.3	Rly3 Options	L.O.E. Alarm		
8.3.1.1	R3 Set	NOT APPLICABLE		
8.3.1.2	R3 Reset	NOT APPLICABLE		
Failsafe				
10.1	Relay 1	Hold State		
10.2	Relay 2	Hold State		
10.3	Relay 3	De-Energise		
10.4	Fail Time	600		
10.5	mA Fail	Hold		
Analogue				
11.1	Analogue O/P	Output 4-20mA		
11.2	Analogue Value	NOT APPLICABLE		
11.3	Test mA	4mA		
11.4	Analogue Scale	NO VALUE REQUIRED		
11.4.1	Datum (%)	0.0		
11.4.2	Span (%)	100.0		
Miscellaneous				
12.1	Offset	0.000		
12.2	Passcode	36.67		
12.3	NoOfDecimal	2 Dec Points		
12.4	Relay tot.	Off		
12.5	Simulation	No		
12.6	Station ID	1		
12.7	Sync Instrs	Master		
12.8	Check Search	Off		
12.9	Maximum gain	100.0		
12.10	Serial Number Store	Serial Number		
12.11	Rev. Number Store	Revision Number		
12.12	Echo Velocity	344.1		
12.13	Gain Control	Variable		
12.14	Transducer	R*TK15-ATEX		

NOT APPLICABLE – Parameter is not required for the selected option but may need to be set if the option is changed.

NO VALUE REQUIRED – This parameter is just a heading and leads to another parameter.

VOLUME APPLICATION PARAMETERS				
Pr	Description	Factory Default	User	Service
Application				
1.0	Basic Application	Level		
Basic Set-up				
2.0	Empty Distance	6.000		
3.0	Operational Span	5.500		
4.0	Blanking	0.500		
5.0	RateOfChange	1.000		
Volume Conversion				
6.1	Vessel Shape	Linear		
	h Metres	NOT APPLICABLE		
	R Metres	NOT APPLICABLE		
	Dish L Metres	NOT APPLICABLE		
	Cylindr L Metres	NOT APPLICABLE		
6.2	Display Units	%		
6.3	MaxDisp *100	001.0		
6.4	Disp. Format	Contents		
Relays				
8.1	Rly1 Options	Norm-Energised		
8.1.1.1	R1 Set	90.00%		
8.1.1.2	R1 Reset	85.00%		
8.2	Rly2 Options	Norm-Energised		
8.2.1.1	R2 Set	10.00%		
8.2.1.2	R2 Reset	15.00%		
8.3	Rly3 Options	L.O.E. Alarm		
8.3.1.1	R3 Set	NOT APPLICABLE		
8.3.1.2	R3 Reset	NOT APPLICABLE		
Failsafe				
10.1	Relay 1	Hold State		
10.2	Relay 2	Hold State		
10.3	Relay 3	Hold State		
10.4	Fail Time	600		
10.5	mA Fail	Hold		
Analogue				
11.1	Analogue O/P	Output 4-20mA		
11.2	Analogue Value	NOT APPLICABLE		
11.3	Test mA	4mA		
11.4	Analogue Scale	NO VALUE REQUIRED		
11.4.1	Datum (%)	0.0		
11.4.2	Span (%)	100.0		
Miscellaneous				
12.1	Offset	0.000		
12.2	Passcode	36.67		
12.3	NoOfDecimal	2 Dec Points		
12.4	Relay tot.	Off		
12.5	Simulation	No		
12.6	Station ID	1		
12.7	Sync Instrs	Master		
12.8	Check Search	Off		
12.9	Maximum gain	100.0		
12.10	Serial Number Store	Serial Number		
12.11	Rev. Number Store	Revision Number		
12.12	Echo Velocity	344.1		
12.13	Gain Control	Variable		
12.14	Transducer	R*TK15-ATEX		

NOT APPLICABLE – Parameter is not required for the selected option but may need to be set if the option is changed.

NO VALUE REQUIRED – This parameter is just a heading and leads to another parameter.

PUMP CONTROL APPLICATION PARAMETERS				
Pr	Description	Factory Default	User	Service
Application				
1.0	Basic Application	Pump Control		
Basic Set-up				
2.0	Empty Distance	6.000		
3.0	Operational Span	5.500		
4.0	Blanking	0.500		
5.0	RateOfChange	1.000		
Relays				
8.1	Rly1 Options	Norm-DeEnergised		
8.1.1.1	R1 Set	1.000		
8.1.1.2	R1 Reset	0.500		
8.2	Rly2 Options	Norm-DeEnergised		
8.2.1.1	R2 Set	2.000		
8.2.1.2	R2 Reset	0.500		
8.3	Rly3 Options	L.O.E. Alarm		
8.3.1.1	R3 Set	NOT APPLICABLE		
8.3.1.2	R3 Reset	NOT APPLICABLE		
Pump Controls				
9.1	PumpSequence	Alternate 1&2		
9.2	Duty Standby	Duty Assist		
9.3	Exerciser	0001		
9.4	Tolerance	No Tolerance		
9.5	Maintenance	All pumps in		
9.6	RunOnIntervl	0.000		
9.7	Run On Time	0000		
Failsafe				
10.1	Relay 1	De-Energise		
10.2	Relay 2	De-Energise		
10.3	Relay 3	De-Energise		
10.4	Fail Time	30		
10.5	mA Fail	High		
Analogue				
11.1	Analogue O/P	Output 4-20mA		
11.2	Analogue Value	NOT APPLICABLE		
11.3	Test mA	4mA		
11.4	Analogue Scale	NO VALUE REQUIRED		
11.4.1	Datum (%)	0.0		
11.4.2	Span (%)	100.0		
Miscellaneous				
12.1	Offset	0.000		
12.2	Passcode	36.67		
12.3	NoOfDecimal	2 Dec Points		
12.4	Relay tot.	Off		
12.5	Simulation	No		
12.6	Station ID	1		
12.7	Sync Instrs	Master		
12.8	Check Search	Off		
12.9	Maximum gain	100.0		
12.10	Serial Number Store	Serial Number		
12.11	Rev. Number Store	Revision Number		
12.12	Echo Velocity	344.1		
12.13	Gain Control	Variable		
12.14	Transducer	R*TK15-ATEX		

NOT APPLICABLE – Parameter is not required for the selected option but may need to be set if the option is changed.

NO VALUE REQUIRED – This parameter is just a heading and leads to another parameter.

OCM APPLICATION PARAMETERS														
Pr	Description	Factory Default			User			Service						
Application														
1.0	Basic Application	Open Channel Flow Monitoring												
Basic Set-up														
2.0	Empty Distance	1.200												
3.0	Operational Span	0.280												
4.0	Blanking	0.500												
5.0	RateOfChange	1.000												
Open Channel Flow														
7.1	Flow Device	Rect.Flume 3/2												
If Flow device is a BS3680 rectangular flume / weir or V-Notch weir enter details in boxes below														
		FD	User	Serv			FD	User	Serv			FD	User	Serv
BS3680 Rect. Flume	Throat Width (m)	N/A			BS3680 Rect. Weir	Crest Width (m)	N/A			BS3680 V-Notch Weir	Angle (Degrees)	N/A		
	Channel Width (m)	N/A				Channel Width (m)	N/A				Channel Width (m)	N/A		
	Throat Length (m)	N/A				Crest Height (m)	N/A				Vertex Height (m)	N/A		
	Hump Height (m)	N/A												
7.2	Max Flow Val	*Only used in BS3680												
7.3	Maximum Flow	50.00												
7.4	Flow Units	in Litres												
7.5	Flow Timebase	in Seconds												
7.6	Total. Units	in m3												
7.7	Ext. Tot. Drv.	0.000												
7.8	Total. Reset	No												
Relays														
8.1	Rly1 Options	Flow Alarm												
8.1.1.1	R1 Set	45.00												
8.1.1.2	R1 Reset	40.00												
8.2	Rly2 Options	L.O.E. Alarm												
8.2.1.1	R2 Set	NOT APPLICABLE												
8.2.1.2	R2 Reset	NOT APPLICABLE												
8.3	Rly3 Options	Totaliser Output												
8.3.1.1	R3 Set	NOT APPLICABLE												
8.3.1.2	R3 Reset	NOT APPLICABLE												
Failsafe														
10.1	Relay 1	De-Energise												
10.2	Relay 2	De-Energise												
10.3	Relay 3	NOT APPLICABLE												
10.4	Fail Time	30												
10.5	mA Fail	Hold												
Analogue														
11.1	Analogue O/P	Output 4-20mA												
11.2	Analogue Value	Relative to flow												
11.3	Test mA	4mA												
11.4	Analogue Scale	NO VALUE REQUIRED												
11.4.1	Datum (%)	0.0												
11.4.2	Span (%)	100.0												

Cont'd...

Miscellaneous				
12.1	Offset	0.000		
12.2	Passcode	36.67		
12.3	NoOfDecimal	2 Dec Points		
12.4	Relay tot.	Off		
12.5	Simulation	No		
12.6	Station ID	1		
12.7	Sync Instrs	Master		
12.8	Check Search	Off		
12.9	Maximum gain	100.0		
12.10	Serial Number Store	Serial Number		
12.11	Rev. Number Store	Revision Number		
12.12	Echo Velocity	344.1		
12.13	Gain Control	Variable		
12.14	Transducer	R*TK15-ATEX		

NOT APPLICABLE – Parameter is not required for the selected option but may need to be set if the option is changed.

NO VALUE REQUIRED – This parameter is just a heading and leads to another parameter.

DIFFERENTIAL LEVEL APPLICATION PARAMETERS				
Pr	Description	Factory Default	User	Service
Application				
1.0	Basic Application	Differential Measurement		
Basic Set-up				
2.0	Empty Distance	2.000		
3.0	Operational Span	0.500		
4.0	Blanking	0.500		
5.0	RateOfChange	1.000		
Relays				
8.1	Rly1 Options	Diff. Control		
8.1.1.1	R1 Set	0.150		
8.1.1.2	R1 Reset	0.050		
8.2	Rly2 Options	Upstream Alarm		
8.2.1.1	R2 Set	0.600		
8.2.1.2	R2 Reset	0.550		
8.3	Rly3 Options	NOT AVAILABLE <i>Used to switch between transducers</i>		
Failsafe				
10.1	Relay 1	Energise		
10.2	Relay 2	De-Energise		
10.3	Relay 3	NOT AVAILABLE		
10.4	Fail Time	600		
10.5	mA Fail	Hold		
Analogue				
11.1	Analogue O/P	Output 4-20mA		
11.2	Analog. Value	Differential		
11.3	Test mA	4mA		
11.4	Analogue Scale	NO VALUE REQUIRED		
11.4.1	Datum (%)	0.0		
11.4.2	Span (%)	100.0		
Miscellaneous				
12.1	Offset	0.000		
12.2	Passcode	36.67		
12.3	NoOfDecimal	2 Dec Points		
12.4	Relay tot.	On		
12.5	Simulation	No		
12.6	Station ID	1		
12.7	Sync Instrs	Master		
12.8	Check Search	Off		
12.9	Maximum gain	100.0		
12.10	Serial Number Store	Serial Number		
12.11	Rev. Number Store	Revision Number		
12.12	Echo Velocity	344.1		
12.13	Gain Control	Variable		
12.14	Transducer	R*TK15-ATEX		

NOT APPLICABLE – Parameter is not required for the selected option but may need to be set if the option is changed.

NOT AVAILABLE – Parameter does not apply to this application type.

NO VALUE REQUIRED – This parameter is just a heading and leads to another parameter.

PARSHALL FLUMES

The OCM flow exponent (Pr.7.1) has been expanded to include 10 Parshall flume profiles. The data for the selected flume are loaded into the flume mapping system (Appendix 1) from tables held in memory.

Maximum head is entered in Pr.3.0 and the associated maximum flow in Pr.7.3. If one of the values is known, the other can be found in the flume tables or by calculation from :


$$Q = KH^n \text{ GPM,}$$

where H = Inches, Q = US GPM and K = Constant for flume size
(for imperial gallon multiply K factor by 0.8).

Flume Size - Inches	K Factor for US GPM	Flume Size - Feet	K Factor for US GPM
1	3.22	10	331.60
2	6.45	12	393.70
3	9.46	15	486.90
6	18.20	20	642.10
9	30.80	30	797.40
12	40.90	40	1263.00
18	58.90	50	1574.00
24	76.30		
36	110.00		
48	142.00		
72	204.70		
96	256.60		

WIRING DIAGRAM FOR SYNCHRONISATION OF INSTRUMENTS


If two or more instruments are situated close together or the transducers beam profile overlaps there is a possibility they can interfere with each other.




Potential problem application with two instruments located close together.


To solve this problem, connect the sync and shield terminals of each of the units in close proximity to each other as shown below.


To program one instrument as master give it the ID number 1 (Pr 12.6 = 1) then set each of the attached instruments as slaves (Pr. 12.7 = Slave) with consecutive ID numbers, up to a maximum of 5.





Connection diagram for up to 5 instruments

















Relay failsafe – default status for different applications

	*10.1 Relay 1	*10.2 Relay 2	*10.3 Relay 3	*10.4 Fail Time	*10.5 mA Fail
LEVEL / VOLUME / DISTANCE	Hold State	Hold State	Hold State	600	Hold
PUMP	De-Energise	De-energise	De-energise	30	High
OCM	De-Energise	De-energise	De-energise	30	Hold
DIFFERENTIAL	Energise	De-Energise	N/A	600	Hold

